

Towing Checklist (for Acadia)

1. Transmission in Park, Ignition off
2. Connect car to motorhome
 - a. Count 7 connections
- 3. Turn Key to Accessory Position**
- 4. Shift Transmission to Neutral**
5. Install Brake Notification Light
6. Remove (switch off) BATT1 fuse

After Towing

1. Re-install BATT1 fuse
2. Shift Transmission to Park
3. Turn Ignition Key Off
4. Disconnect car from motorhome
5. Re-set Date & Time on dash